


Instructions Manual

WKF030

Eye Massager



VERSION 6.26


Dear Customers:

Thank you for purchasing the Hisooth E10 Smart Eye Massager. This concise, stylish, and portable product is safe and reliable after being rigorously tested. The 180° folding product through high-frequency motor vibration and hot compress of heating film, can relax the eye muscles, relieve eye fatigue, and promote blood circulation. Please read this manual carefully before you use it so as to correctly use this product. (Note: Hisooth reserves the right to change the design and final interpretation of the product. If there is any change without notice, the color and appearance of the product are subject to the actual product.)



Imported by
WEEKKO BARCELONA SL
Pol. Ind. La Vall d'an
Cami de Garreta, 92
08600 Berga
Barcelona - Spain
T. +34 93 824 90 20
E. info@weekko.com

Configuration



Product Parameters

Product Name: E10 Smart Eye Massager

Folding Size: 82.9 × 57.9 × 55.1mm / 3.26" x 2.28" x 2.17"

Unfolded Size: 156.8 × 58 × 47.4mm / 6.17" x 2.28" x 1.87"

Rated Voltage: DC3.7V

Rated Power: 4.0W

Charging Voltage: DC5.0V

Battery Capacity: 1000mAh

Smart Timer: 10 minutes

Executive Standard: GB 4706.1-2005

GB 4706.10-2008

*Note: this product is not a substitute for medical devices.

Features

- High Frequency Vibration.
- 4 Modes: Vitality, Soothing, Eye-care, Sleep Mode.
- Cordless with view window.
- 180° Foldable.
- 3 Levels of Intensity (High-Mid-Low).
- 3 Levels of Heating (40°C/104°F, 42°C/107.6°F, 45°C/113 °F).
- Smart Timer (10 minutes).
- Small and Portable.
- Adjustable strap for different people.

Operation

- Put on: wear the eye massager to adjust it to a comfortable status.
- Power on: press and hold [] for 1.5s to turn on/off the device. Active Mode will be automatically on with moderate vibration. The battery displays its power level.
- Mode adjustment: short press [] to switch the modes cyclically: Active Mode, Soothing Mode, Eye-care Mode, Sleep Mode, Active Mode.

Operation

- Intensity adjustment: short press [] intensity button to adjust the intensity Level 1-Level 2-Level 3-Off cyclically. Level 2 intensity is automatically on when the device is turned on. Power indicator shows the current power .
- Heating: short press [] to turn on/off the heating. 40°C/104°F is the default heating level and short press the heating button to adjust the heating level cyclically:
40°C/104°F -42°C/107.6°F-45°C/113°F-Off.
- Power Off: press and hold [] 1.5S to turn on/off the device and all functions.
- Massage Duration: the massage will stop in 10 minutes .
- Low Power: when the power is low, all the functions will stop and the indicator will indicate that the power is low and only last stage of battery indicator will keep flashing.
- Charging: Use USB-C charging cable to charge the device; during charging, the battery indicators are flashing; all the indicators are illuminating when the charging is finished.

Disclaimer

Warnings & Precautions

a) Contraindication

1. People with symptoms of eye diseases such as glaucoma, cataracts, and retinal detachment.
2. Patients with deep stroke, hypertension and hypotension.
3. It is prohibited to use during the onset of patients with moderate and severe cardiovascular disease and severe heart disease.
4. It is forbidden for those with eye skin perception disorder or eye skin abnormality.
5. Contraindicated in patients with eye pain.
6. Patients in the rehabilitation stage after eye surgery.
7. Pregnant women are prohibited.
8. Those with unhealed wounds after surgery are prohibited.
9. Patients who are undergoing treatment and feel physically abnormal.
10. Patients with hypertension, high intraocular pressure, arteriosclerosis or cerebral thrombosis.
11. Patients with high fever, malignant tumor and osteoporosis.
12. People who cannot take care of themselves, infants or people who are not sensitive to heat are prohibited.

b) Safety Instructions

1. Please turn off the power when not using this product.

Disclaimer

2. For your safety, please turn off the power of the product before sleep.
3. It is forbidden to approach fire sources, corrosive liquids and various unfavorable environments.
4. Do not wash, if the product gets wet, it must be completely dry before you open it for use.
5. Clean the surface with a damp cloth or neutral detergent and let it dry naturally.
6. Do not use the product while charging.
7. Do not wear contact lenses when using this product.
8. Do not use while driving or after drinking alcohol.
9. This product contains lithium battery, please do not disassemble, modify or throw it into fire to avoid danger.
10. Do not use this product continuously for a long time, otherwise it may cause fatigue and discomfort in the massage area.
11. The eye massager is designed as a home electronic health care product and is not intended for diagnostic, therapeutic and other commercial use.

c) Use environment

1. Do not place the product in the bathroom or use it in humid places.
2. Do not place the product in a place with electric heaters, stoves or direct sunlight.
3. Do not use during lightning strikes.

Disclaimer

d) About the power plug and power cord

1. Do not use a power supply with an unexpected rated voltage to charge, please use the original power cord of the product to avoid fire or damage to the product;
2. When unplugging the power cord, hold the plug of the power cord instead of the power cord.
3. If the power cord is damaged, please use a qualified charging cable to replace the damaged one.

Warranty

If within one year from the date of purchase, this product fails due to a defect in material of workmanship, Hisooth will repair or replace the product, or supply necessary components free of charge.

This warranty excludes:

- a) Damage caused by accident, abuse, mishandling, or transport.
- b) Units subjected to unauthorized repair.
- c) Improper use of this device.
- d) Damage exceeding the cost of the product.
- e) Deterioration of the delivered product resulting from abnormal storage and / or safeguarding conditions on the client's premises.
- f) Failure to provide the dated proof of purchase.

Warranty Card

Product Name		Product Model	
Date of Purchase		Customer Name	
Customer Address		Customer Tel	
Tel	400 601 8680/+86 021 37218831		
Mail	customerservice@dandu.net		
Address	No, 10th, Jinfeng Road, Dafeng District, Yancheng City, Jiangsu, CHINA		

Troubleshooting

If the following troubles occur during use, please take the following advice for reference. If the device is still problematic, please stop using it and contact us for check and repair.

Troubleshooting

Problems	Possible Causes	Solutions
The device does not work.	The power is low.	Use the device after it is fully charged.
	You accidentally touch the power button.	short press for 1.5s to turn on the device
Intensity is weak / Heating is not enough.	The power is low.	Charge the battery.
The device fails to charge.	The charging cable is not connected well.	Plug the cable correctly.
	USB Cable is damaged.	Change a new qualified charging cable.
The indicator is working but the device does not work / heat.	The device needs maintenance.	Contact the After-sales center.

- Users are not allowed to disassemble or repair the product by themselves. Damage to the product caused by disassembly or repair by users will invalidate the product warranty, and the company is not responsible for any consequences caused by this situation.



Imported by
WEEKKO BARCELONA SL

Pol. Ind. La Vallidán
Cami de Garreta, 92
08600 Berga
Barcelona - Spain
T. +34 93 824 90 20
E. info@weekko.com

U.S.A

8360 Rovana Cir, Sacramento, CA 95828, U.S.A

Tel: (847) 675-2770, (888) 710-7206

Email: sales@mhpinternational.com

UK

Unit 8 Fareham Industrial Park, Standard Way, Fareham, PO16 8XB, UK

Tel: +44 0132 9750 820

Email: uk@mhpinternational.com

Deutschland

Striekenkamp 40, 28777 Bremen

Tel: +49 (0)421 60956677

Email: order@mhpinternational.de

中国

江苏省盐城市大丰区锦丰路10号

Email: dandu@dandu.net